



■ PARTS LIST

| | | | |
|---------------------|-------------------------|---------------------|--------------------|
| 1 THICKNESS HANDLE | 26 GEAR 10T | 51 CAM HOUSING #2 | 76 LOCK WASHER |
| 2 SHAFT | 27 LOCK WASHER | 52 ACTIVE ROLLER | 77 SCREW M12 |
| 3 SCREW | 28 SCREW M10 | 53 BEARING 30209 ZZ | 78 PRODUCT TRAY |
| 4 WASHER | 29 LOCK WASHER | 54 BEARING HOLDER | 79 SCREW |
| 5 LOCK WASHER | 30 BEARING 6205 ZZ | 55 LOCK WASHER | 80 SCREW |
| 6 ADJUSTER #1 | 31 NUT M10 | 56 GEAR 31T | 81 SCREW |
| 7 HOLD PLATE | 32 GEAR HOUSING | 57 CASING | 82 HOUSING |
| 8 ADJUSTER #2 | 33 GEAR 24T | 58 GEAR 18T | 83 GEAR |
| 9 BALLS | 34 TABLE HOLDER | 59 GEAR 18*2T | 84 BEARING 6002 ZZ |
| 10 SPRING | 35 FLOUR RECEIVING DISH | 60 CASING | 85 LOCK WASHER R35 |
| 11 ADJUSTER #3 | 36 FLOUR TRAY | 61 HOLDER | 86 LOCK WASHER S15 |
| 12 CASING | 37 SHAFT | 62 LOCKWASHER | 87 CONVEYOR |
| 13 BEARING 6205 ZZ | 38 SHAFT | 63 NUT | 88 SHAFT (HANDLE) |
| 14 PIN | 39 GEAR 15T | 64 TOP SCRAPER | 89 POWER SWITCH |
| 15 GEAR 15T | 40 UPPER PRESS HOLDER | 65 BOTTOM SCRAPER | 90 STOP SWITCH |
| 16 GEAR 21T | 41 ROLLER | 66 HOLDER | 91 SAFETY GUARD |
| 17 CAM HOUSING #1 | 42 LOWER PRESS ROLLER | 67 SPRING | 92 HOLDER |
| 18 CAM | 43 BEARING 6206 ZZ | 68 SPRING | 93 PLATE |
| 19 SCREW M8 | 44 PIN | 69 TABLE | 94 FOOT SWITCH |
| 20 WASHER | 45 PIN | 70 PLATE | 95 COVER |
| 21 GEAR 15T | 46 BEARING 6004 ZZ | 71 UPPER | 96 SUPPORT |
| 22 GEAR 27T | 47 SHAFT | 72 NUT | 97 WHEEL |
| 23 BEARING 51108 ZZ | 48 HOLDER | 73 TABLE SUPPORT | 98 WHEEL |
| 24 HOLDER | 49 BEARING 6203 ZZ | 74 ROLLER COMPLE | 99 BASE |
| 25 SHAFT | 50 HOLDER | 75 SHAFT | 100 |



